



FEATURES

- ➔ Transmitter for the AMPLICALL range
- ➔ Can be paired with an AMPLICALL 100 or/and an AMPLICALL 150, but can also be used alone
- ➔ LED visual ringer indicator
- ➔ Loud ringer: 90 dB
- ➔ Adjustable volume: Loud / Medium / Low
- ➔ Emergency call button (when paired with AC100 or AC150)
- ➔ Range between the emitter and the receiver:
 - Indoor: up to 35m
 - Open field: up to 200m

TECHNICAL SPECIFICATIONS

- ➔ Desk or wall mountable
- ➔ Supplied with a RJ11 phone line cord included (30cm)
- ➔ Works with the 2 included AA type batteries or with a 5VDC USB type C adaptor (not included)
- ➔ 2 RJ11 plugs
- ➔ Adaptor jack (option) 3.5mm for external captor
- ➔ Frequency: 868MHz
- ➔ Dimensions: 10,1 x 9,8 x 3,6 cm

OPTIONAL EXTRAS

- ➔ Power supply (5VDC)

PRODUITS COMPATIBLES

- ➔ AMPLICALL 150, AMPLICALL 100